



Locator flow chart: New Denture

First Appointment:

- * Remove healing abutment – Measure depth of tissue, From the top of the Prosthetic head. Buccal, Mesial, Distal, Lingual.
- * Use this measurement to order abutments and Impression copings.
- * Choose locator abutment that is 1mm taller than your greatest depth
- * Replace healing abutments.
- * Take impression for custom tray (two days in Lab.)

Second Appointment:

- * Remove healing abutment.
- * Place Locator abutments using a locator tool.
- * Take impression. Using Locator impression copings
- * Replace healing abutments, Pay special attention to abutment location if abutments are differing lengths.
- * Send impression and all retentive males to Laboratory. Rx requesting Base plate and Wax Rims (two days in Lab.)

Third Appointment:

- * Take Bite registration and return for Set-up. (two days in Lab.)

Fourth Appointment:

- * Try-in wax-up and verify bite.
- * Return for proses. (Two days in Lab.)

Fifth Appointment:

- * Insert Denture. Torque locator abutments to 30Ncm.
- * Denture will be returned with a 3.0 lb. Pink retentive male. Unless specified. The clear 5.0 lb. and the blue 1.5 lb. Are also included.